



SINTEF



Constrained Pressure Residual (CPR) preconditioners in OPM Flow

Halvor Møll Nilsen, Atgeirr Flø Rasmussen, Computational Geosciences, SINTEF Digital

OPM Summit, August 28 - 29, Trondheim, Norway

Presentation outline

- Motivation
- Constrained Pressure Residual (CPR) preconditioner
- Numerical performance
- Outlook and concluding remarks





Presentation outline

Motivation

Constrained Pressure Residual (CPR) preconditioner

Numerical performance

Outlook and concluding remarks



Motivation

- Linear solves uses between 50-90 % simulation time
 - NORNE: 50 % ($np = 8$, $tol = 0.01$, ILUo, old assembly)
- Robust linear solves for high accuracy with limmited performanc overhead:
 - reduce Newton iterations
 - avoid time used on difficult linear systems
- CPR is seen as state of the art solver for Black-Oil Multiphase flow



Motivation

- Linear solves uses between 50-90 % simulation time
 - NORNE: 50 % ($np = 8$, $tol = 0.01$, ILUo, old assembly)
- Robust linear solves for high accuracy with limmited performanc overhead:
 - reduce Newton iterations
 - avoid time used on difficult linear systems
- CPR is seen as state of the art solver for Black-Oil Multiphase flow

Aim: Provide robust accurate solver for Reservoir Simulations in OPM

Presentation outline

- Motivation
- Constrained Pressure Residual (CPR) preconditioner
- Numerical performance
- Outlook and concluding remarks



Preconditioning strategies

- "Algebraic Multigrid type":
 - Hierarchical
 - "Oscillate" between different type smoothers (small scale) and coarse scale solves (large scale)
- Schwartz type: "domain decomposition"
 - Domain based
 - Physics based
- Field split
 - Approximate inverse using approximate inverses of subsystems

AMG type: General linear solver framework: OPM Flow



AMG type: Building block

Solves on one level

Global solve is often only applying one approximate solve i.e. (resulting in V-cycle).

OPM Flow: reduced linear solver

- Full system:

$$A = \begin{pmatrix} A_{rr} & A_{rw} \\ A_{wr} & A_{ww} \end{pmatrix} \quad A \begin{pmatrix} x_r \\ x_w \end{pmatrix} = \begin{pmatrix} r_r \\ r_w \end{pmatrix}$$

- Schur-complement system:

$$S(A) = A_{rr} - A_{rw}A_{ww}^{-1}A_{wr} \quad \text{and} \quad S(r_r) = r_r - A_{rw}A_{ww}^{-1}r_w.$$

$$S(A)x_r = S(r_r)$$

- Equivalent Large system:

$$A \begin{pmatrix} x_r \\ x_w \end{pmatrix} = \begin{pmatrix} S(r_r) \\ 0 \end{pmatrix}$$

$$x_w = x_w - A_{ww}^{-1}r_w.$$

CPR original approach: OPM Flow

- CPR with fill in:

$$R_{er}S(A)R_{vr}^T x_{rp} = R_{er}S(r_r)$$

- Equivalent extended system

$$\begin{array}{cc} R_{er}A_{rr}R_{vr}^T & R_{er}A_{rw} \\ A_{wr}R_{vr}^T & A_{ww} \end{array} \begin{array}{c} x_{rp} \\ x_w \end{array} = \begin{array}{c} R_{er}S(r_r) \\ 0 \end{array}$$

- CPR with out fill in (bug found):

$$R_{er}A_{rr}R_{vr}^T = R_{er}S(r_r)$$

New CPR with wells: OPM Flow

- Problems with traditional:
 - Block structure of wells and reservoir is different
 - Few iterations ! Schur complement $n_{perf_i}^2$ fill in
 - No fill in ! more iterations
- Observation: pressure system has no block structure
- Idea extend pressure system to a well pressure system





SINTEF

Presentation outline

Motivation
Constrained Pressure Residual (CPR) pre-
conditioner

Numerical performance

Outlook and concluding remarks



Small systems

| Type | add _w | Newit | LinIt | tol |
|-------|------------------|-------|-------|------|
| ParO3 | False | 408 | 3156 | 0.01 |
| ParO3 | True | 411 | 3180 | 0.01 |
| cprw3 | False | 349 | 310 | 0.01 |
| cpr3 | True | 352 | 297 | 0.01 |
| cpr3 | False | 357 | 494 | 0.01 |







| np | Type | add _w | total | Ass | LTot | LApp | LSet | Newit | LinIt | tol |
|----|-------|------------------|-------|-----|------|------|------|-------|-------|------|
| 1 | cpr3 | True | 788 | 404 | 232 | 117 | 115 | 1225 | 1671 | 0.01 |
| 1 | cprw3 | False | 788 | 400 | 238 | 132 | 106 | 1218 | 2057 | 0.01 |
| 1 | cpr3 | False | 871 | 402 | 317 | 209 | 108 | 1235 | 3373 | 0.01 |
| 1 | ParO3 | True | 964 | 427 | 357 | 311 | 46 | 1505 | 21223 | 0.01 |
| 1 | ParO3 | False | 1045 | 473 | 386 | 339 | 47 | 1441 | 21440 | 0.01 |

| np | Type | add _w | total | Ass | LTot | LApp | LSet | Newit | LinIt | tol |
|----|-------|------------------|-------|-----|------|------|------|-------|-------|------|
| 4 | cprw3 | False | 281 | 140 | 97 | 52 | 44 | 1181 | 2435 | 0.01 |
| 4 | cpr3 | True | 288 | 142 | 100 | 54 | 46 | 1223 | 2205 | 0.01 |
| 4 | cpr3 | False | 303 | 142 | 117 | 74 | 43 | 1227 | 3421 | 0.01 |
| 4 | ParO3 | False | 330 | 163 | 115 | 102 | 13 | 1412 | 21212 | 0.01 |
| 4 | ParO3 | True | 346 | 168 | 124 | 110 | 14 | 1464 | 21081 | 0.01 |



SINTEF

Volve



<https://discovervolve.com/2021/09/25/how-to-run-the-volve-oilfield-dynamic-model-in-opm-flow/>

CPR problems




- Small timesteps where linear solves is easy
- Difficult nonlinear solves, where a lot of linear solves are wasted
- If character of nonlinear solver is
- Any other?



SINTEF

Presentation outline

- Motivation
- Constrained Pressure Residual (CPR) preconditioner
- Numerical performance
- Outlook and concluding remarks



Outlook and challenges

- New investigations
 - Flexible solvers on top level
 - Approaches with flexible on all levels
 - Changing linear solvers to avoid performance penalties of CPR when small time-steps is used.
 - New approaches for new CPR for VFP and multisegement wells
- Challenges:
 - Avoid wasted solves
 - Correct exit strategies (maxiter/tol)
 - Minimizing setup time by reuse

Outlook and challenges

- New investigations
 - Flexible solvers on top level
 - Approaches with flexible on all levels
 - Changing linear solvers to avoid performance penalties of CPR when small time-steps is used.
 - New approaches for new CPR for VFP and multisegement wells
- Challenges:
 - Avoid wasted solves
 - Correct exit strategies (maxiter/tol)
 - Minimizing setup time by reuse

Do OPM flow need working solvers with other cPR/AMG types available
AMGCL/PETSC? (flow_blackoil_amgcl, flow_blackoil_petsc)

Conclusion

- CPR is particular good on:
 - cases which require accurate linear solves (for correct newton)
 - cases with long timesteps
 - cases with few steps with problematic timestep cuts
 - tight tolerances
- It is critical:
 - to minimize work on wasted linear solves
 - reuse setup
- **New CPR with wells seem to be the best CPR on several of the test cases**
- CPR is so far shown to be best preconditioner for NORNE, VOLVE,